

Web-Client

Der Web-Client Starter stellt die exklusive Anzeige einer Webseite oder Web-Visualisierung im Vollbild sicher. Dabei wird verhindert, dass der Bediener ausbrechen und ins Betriebssystem gelangen kann.


Zur Einrichtung gehen Sie bitte wie folgt vor:

Tragen Sie die gewünschte Adresse ein, die der Browser starten soll.

Wählen Sie den Browser aus, der verwendet werden soll. Dieser muss auf dem System installiert sein.

Danach den Kioskmodus aktivieren.

Nun mit "Starten" den Web-Client ausführen.



The image shows a screenshot of the 'VisuStarter' application window. The window has a dark title bar with the text 'VisuStarter' on the left and a globe icon with a dropdown arrow on the right. Below the title bar, there are four rows of controls, each with a label on the left, a small box with a question mark in the middle, and a button on the right. The first row is labeled 'Web' and has a 'Starten' button. The second row is labeled 'Adresse' and has a text input field containing the URL 'https://www.SmartHomeTools.de'. The third row is labeled 'Browser' and has a dropdown menu showing 'Edge'. The fourth row is labeled 'Kiosk / Autostart' and has a dropdown menu showing 'Aus'.

Label	Question Mark	Action
Web	?	Starten
Adresse		<input type="text" value="https://www.SmartHomeTools.de"/>
Browser	?	Edge
Kiosk / Autostart	?	Aus

Revision #4

Created 17 January 2025 09:11:41 by Unhye Lee

Updated 20 January 2025 18:31:00 by Benjamin Schneider