

Web client

The Web Client Starter ensures the exclusive display of a website or web visualization in full screen. This prevents the user from breaking out and accessing the operating system.


To set up, please proceed as follows:

Enter the desired address that the browser should start.

Select the browser to be used. This must be installed on the system.

Then activate the kiosk mode.

Now click "Start" to run the web client.



The image shows a software window titled "VisuStarter" with a globe icon and a dropdown arrow in the top right corner. The window contains four rows of configuration options, each with a label, a question mark icon, and a control element:

- Web**: A text input field containing a question mark and a "Start" button.
- Address**: A text input field containing the URL `https://www.SmartHomeTools.de`.
- Browser**: A dropdown menu with "Edge" selected and a downward arrow.
- Kiosk / Autostart**: A dropdown menu with "Off" selected and a downward arrow.

Revision #2

Created 20 January 2025 09:06:54 by Unhye Lee

Updated 20 January 2025 18:34:43 by Benjamin Schneider